

falmec



Design

Luce





Island/Isola

INSTRUCTIONS BOOKLET

LIBRETTO ISTRUZIONI ^{IT}
GEBRAUCHSANWEISUNG ^{DE}
MODE D'EMPLOI ^{FR}
MANUAL DE INSTRUCCIONES ^{ES}

ИНСТРУКЦИИ ^{RU}
INSTRUKCJA OBSŁUGI ^{PL}
HANDLEIDING ^{NL}
MANUAL DE INSTRUÇÕES ^{PT}

BRUGSANIVSNINGER ^{DK}
INSTRUKTIONSBOK ^{SE}
OHJEKIRJA ^{FI}
BRUKSANVISNING ^{NO}






800
m³/h



LUCE ISOLA:

32 KG





Uscita laterale utilizzabile solo con controsoffitto.

Side outlet which can only be used with false ceiling.

Seitlicher Abzug nur mit Zwischendecke verwendbar.

Sortie latérale utilisable uniquement avec faux-plafond.

Salida lateral utilizable solo con falso techo.

Боковой выход, используемый лишь при наличии подвесного потолка.

Wylot boczny, wykorzystywany tylko na sufitach podwieszanych.

Zijdelingse uitgang enkel bruikbaar met vals plafond.


Saída lateral utilizável apenas com revestimento do teto.

Udgang på siden kun til anvendelse med nedhængt loft.

Sidoutgång endast användbar med undertak.

Sivussa oleva poistoaukko käytettävissä vain sisäkaton kanssa.

Sideutgang som kun kan brukes med undertak.



IT - Operazioni preliminari: separare traliccio superiore da traliccio inferiore (1). Rimozione filtri (2).

EN - Preliminary operations: separate upper trellis from lower trellis (1). Filter removal (2).

DE - Vorbereitende Vorgänge: die obere Strebe von der unteren Strebe trennen (1). Entfernung Filter (2).

FR - Opérations préliminaires: séparer le rail supérieur du rail inférieur (1). Retrait des filtres (2).

ES - Operaciones preliminares: separar la estructura superior de la estructura inferior (1). Extracción de filtros (2).

RU - Предварительные операции: отделите верхнюю конструкцию от нижней (1). Снятие фильтров (2).

PL - Operacje wstępne: oddzielić górny słup d słupa dolnego (1). Zdjęcie filtrów (2).

NL - Voorbereidingen: scheid het bovenste raamwerk van het onderste raamwerk (1). Verwijdering filters (2).


PT - Operações preliminares: separar a treliça superior da treliça inferior (1). Remoção filtros (2).

DK - Forberedelser: skil den øverste tværdrager fra den nederste (1). Udtagning af filtre (2).


SE - Förberedande arbeten: separera det övre fackverket från det nedre fackverket (1). Borttagning av filter (2).

FI - Esitoimenpiteet: erota yläsäleikkö alasäleiköstä (1). Kokoaminen suodattimien (2) irrottaminen.

NO - Forberedende operasjoner: Skill det øvre listverket fra det nedre listverket (1). Fjerning av filtre (2).



2



IT - Installazione a soitto (3), installazione a controsoitto(4) e installazione a soitto senza prolunga camino e traliccio superiore (5).

EN - Ceiling installation (3), false ceiling installation (4) and ceiling installation without chimney extension and upper trestle (5).

DE - Deckeninstallation (3), Zwischendeckeninstallation (4) und Deckeninstallation ohne Abluftkaminverlängerung und obere Strebe (5).

FR - Installation au plafond (3), installation sur faux-plafond (4) et installation au plafond sans extension de cheminée et sans rail de fixation supérieure (5).

ES - Instalación en el techo (3), instalación en el contratecho (4) e instalación en el techo sin extensión de chimenea y poste superior (5).

RU - Монтаж на потолок (3), монтаж на подвесной потолок (4) и монтаж на потолок без удлинителя дымохода и верхнего каркаса (5).

PL - Instalacja na suicie (3), instalacja na suicie podwieszanym (4) i instalacja na suicie bez przedłużenia komina i kratki górnej (5).

NL - Installatie aan het plafond (3), installatie aan het verlaagd plafond (4) en installatie aan het plafond zonder verlenging schoorsteen en bovenste raamwerk (5).

PT - Instalação no teto (3), instalação em teto falso (4) e instalação no teto sem extensão chaminé e treliça superior (5).


DK - Installation i loftet (3), installation i nedsænket loft (4) og installation i loft uden kaminforlængelse og øvre stålskelet (5).

SE - Takmontering (3), undertaksmontering (4) och takmontering utan förlängning av kåpa och övre galler (5).


FI - Kattoasennus (3), välikattoasennus (4) ja kattoasennus ilman hormijatketta ja yläsäleikköä (5).

NO - Installasjon i tak (3), installasjon i undertak (4) og installasjon i tak uten pipeforlengelse og øvre listverk (5).


3



4



5



 Gas (min.)	 Induction (min.)
630 mm	520 mm

IT - Montaggio traliccio (6) e prolunga (7).

EN - Trestle (6) and extension (7) assembly.

DE - Montage Gittermast (6) und Verlängerung (7).

FR - Montage support de fixation (6) et rallonge (7).

ES - Montaje estructura (6) y prolongación (7).

RU - Монтаж каркаса (6) и удлинителя (7).

PL - Montaż kratki (6) i przedłużenia (7).

NL - Montage raamwerk (6) en extensie (7).



PT - Montagem treliça (6) e extensão (7).

DK - Montering af tværbjælke (6) og forlængerstykke (7).

SE - Montering av fackverk (6) och förlängning (7).

FI - Säleikön (6) ja jatkeen (7) asennus.

NO - Montering av listverk (6) og forlengelse (7).



IT - Installazione a soffitto senza traliccio superiore e senza prolunga (8).

EN - Ceiling mount without upper trestle and without extension (8).

DE - Installation an Decke ohne oberen Gittermast und ohne Verlängerung (8).

FR - Installation sur plafond sans support de fixation supérieur et sans rallonge (8).

ES - Instalación en techo sin estructura superior y sin prolongación (8).

RU - Установка на потолок без верхнего каркаса и без удлинителя (8).

PL - Instalacja na suficie bez kratki górnej i przedłużenia (8).

NL - Installatie aan het plafond zonder bovenste raamwerk en extensie (8).

PT - Instalação no teto sem treliça superior e sem extensão (8).


DK - Loftinstallation uden øvre tværbjælke og uden forlængerstykke (8).

SE - Installation i tak utan övre fackverk och utan förlängning (8).

FI - Kattoasennus ilman yläsäleikköä ja jatketta (8).

NO - Installasjon i tak uten øvre listverk og uten forlengelse (8).

8



IT - Montaggio valvola di non ritorno (9); tubo aspirazione (10); assemblaggio camino (11).

EN - Check valve assembly (9); exhaust pipe (10); chimney assembly (11).

DE - Montage Rückschlagventil (9); Ansaugrohr (10); Kamingruppe (11).

FR - Montage clapet anti-retour (9) ; tube d'aspiration (10) ; assemblage conduit d'évacuation (11).

ES - Montaje de válvula de no retorno (9); tubo de aspiración (10); montaje de chimenea (11).

RU - Монтаж обратного клапана (9); всасывающей трубы (10); сборка дымохода (11).

PL - Montaż zaworu zwrotnego (9), rury zasysającej (10); montaż komina (11).

NL - Montage terugslagklep (9); inlaatleiding (10); assemblage schoorsteen (11).

PT - Montagem da válvula de não retorno (9); tubo aspiração (10); montagem chaminé (11).


DK - Montering af kontraventil (9); udsugningsrør (10); montering af skorsten (11).

SE - Montering av backventil (9); sugledning (10); sammansättning av skorsten (11).


FI - Vastaventtiilin (9), imuputken (10) asennus; savupiipun kokoonpano (11).

NO - Montering av stengeventil (9), oppsugingsrør (10), montering av pipe (11).


9



10



11



IT - Configurazione a soffitto (12);
Configurazione a controsoffitto (13)(14).

EN - Ceiling configuration (12);
False ceiling configuration (13)(14).

DE - Konfiguration Decke (12);
Konfiguration abgehängte Decke (13)(14).

FR - Installation sur plafond (12);
Installation sur faux-plafond (13)(14).

ES - Configuración en techo (12);
Configuración en falso techo (13)(14).

RU - Конфигурация на потолке (12);
Конфигурация на подвесном потолке (13)(14).

PL - Konfiguracja na suficie (12);
Konfiguracja na suficie podwieszanym (13)(14).

NL - Configuratie aan plafond (12);
Configuratie aan verlaagd plafond (13)(14).

PT - Configuração no teto (12);
Configuração em teto falso (13)(14).


DK - Loftskonfiguration (12);
Konfiguration med nedsænket loft (13)(14).

SE - Utförande för innertak (12);
Utförande för undertak (13)(14).


FI - Asetus kattoon (12);
Asetus välikattoon (13)(14).

NO - Konfigurasjon i tak (12);
Konfigurasjon i undertak (13)(14).


12



13



14



IT - Installazione camera motore (15); collegamento elettrico e fissaggio camino + prolunga (16).

EN - Motor chamber installation (15); electrical connection and chimney + extension installation (16).

DE - Installation Motorkammer (15); elektrischer Anschluss und Befestigung Kamin + Verlängerung (16).

FR - Installation chambre moteur (15); branchement électrique et fixation conduit d'évacuation + rallonge (16).

ES - Instalación cámara motor (15); conexión eléctrica y fijación de chimenea + prolongación (16).

RU - Установка камеры двигателя (15); электрическое подключение и крепление дымохода + удлинителя (16).

PL - Instalacja komory silnika (15); połączenie elektryczne i zamocowanie komina + przedłużenia (16).

NL - Installatie kamer motor (15); elektrische aansluiting en bevestiging schoorsteen + extensie (16).

PT - Instalação câmara motor (15); ligação elétrica e fixação da chaminé + extensão (16).


DK - Installation af motorkammer (15); elektrisk tilslutning og fastgøring af skorsten + forlængerstykke (16).

SE - Installation motorhus (15); elanslutning och fastsättning av skorsten + förlängning (16).


FI - Moottorikotelon (15) asennus; sähkökytkentä ja hormin + jatkeen (16) kiinnitys.

NO - Installasjon av motorrom (15), elektrisk tilkobling og feste av pipe + forlengelse (16).

15



16



IT - Installazione su soffitto senza prolunga (H) e traliccio (T)
(17) (18).

EN - Installation on ceiling without extension (H) and trellis (T)
(17) (18).

DE - Deckeninstallation ohne verlängerung (H) und gitter (T)
(17) (18).

FR - Installation au plafond sans rallonge (H) ni treillis (T)
(17) (18).

ES - Instalación en techo sin extensión (H) y enrejado (T)
(17) (18).

RU - Установка на потолок без удлинителя (H) и каркасного
элемента (T) (17) (18).

PL - Montaż na suficie bez przedłużki (H) i wysięgnika (T)
(17) (18).

NL - Installatie op het plafond zonder verlengstuk (H) en
schacht (T) (17) (18).

PT - Instalação no teto sem extensão (H) e treliça (T) (17) (18).


DK - Installation i loft uden forlænger (H) og tremmer (17) (18).

SE - Montering i tak utan förlängning (H) och fackverk (T)
(17) (18).





FI - Asennus kattoon ilman jatkokappaletta (H) ja kehikko (T)
(17) (18).

NO - Installasjon på tak uten skjøteelement (H) og gitterverk (T)
(17) (18).


17



18



IT - Viti di sicurezza obbligatorie
EN - Mandatory safety screws
DE - Sicherheitsschrauben, obligatorisch
FR - Vis de sécurité obligatoires
ES - Tornillos de seguridad obligatorios
RU - обязательные предохранительные винты
PL - Obowiązkowe śruby zabezpieczające
NL - Verplichte veiligheidsschroeven
PT - Parafusos de segurança obrigatórios
DK - Obligatoriske sikkerhedsskruer
SE - Obligatoriska säkerhetsskruvar
FI - Pakolliset varmistusruuvit
NO - Påkrevde sikkerhetsskruer









IT - Montaggio filtro di serie (19+20).
 EN - Assembly of factory-fitted filter (19+20).
 DE - Montage des Serien- (19+20).
 FR - Montage du filtre de série (19+20).
 ES - Montaje del filtro de serie (19+20).
 RU - Монтаж фильтра серийного (19+20).
 PL - Montaż filtra występującego (19+20).

NL - Montage filter, serieel (19+20).
 PT - Montagem filtro de série (19+20).
 DK - Montering af seriefilter (19+20).
 SE - Montering av seriefilter (19+20).
 FI - Varusteluun kuuluvan (19+20) asennus.
 NO - Montering av standardfilter (19+20).



19



20



21



PULIZIA E MANUTENZIONE
MAINTENANCE
REINIGUNG UND WARTUNG
NETTOYAGE ET ENTRETIEN
LIMPIEZA Y MANTENIMIENTO
ОЧИСТКА И УХОД
CZYSZCZENIE I KONSERWACJA
RENGØRING OG VEDLIGEHOLDELSE

SAFETY INSTRUCTIONS AND WARNINGS

 **Installation operations are to be carried out by skilled and qualified installers in accordance with the instructions in this booklet and in compliance with the regulations in force.**

DO NOT use the hood if the power supply cable or other components are damaged: disconnect the hood from the electrical power supply and contact the Dealer or an authorised Servicing Dealer for repairs.

Do not modify the electrical, mechanical or functional structure of the equipment.

Do not personally try to carry out repairs or replacements. Interventions carried out by incompetent and unauthorised persons can cause serious damage to the unit or physical and personal harm, not covered by the Manufacturer's warranty.

WARNINGS FOR THE INSTALLER

TECHNICAL SAFETY

 **Before installing the hood, check the integrity and function of each part. Should anomalies be noted, do not proceed with installation and contact the Dealer.**

Do NOT install the hood if an aesthetic (or cosmetic) defect has been detected. Put it back into its original package and contact the dealer.

No claim can be made for aesthetic (or cosmetic) defects once it has been installed.

During installation, always use personal protective equipment (e.g.: Safety shoes) and adopt prudent and proper conduct.

The installation kit (screws and plugs) supplied with the hood is only to be used on masonry walls: in case of installation on walls of a different material, assess other installation options keeping in mind the type of wall surface and the weight of the hood (indicated on page 2).

Keep in mind that installations with different types of fastening systems from those supplied, or which are not compliant, can cause electrical and mechanical seal danger.

Do not install the hood outdoors and do not expose it to atmospheric elements (rain, wind, etc.).

ELECTRICAL SAFETY

 **The electrical system to which the hood is to be connected must be in accordance with local standards and supplied with earthed connection in compliance with safety regulations in the country of use. It must also comply with European standards regarding radio antistatic properties.**

Before installing the hood, check that the electrical mains power supply corresponds with what is reported on the identification plate located inside the hood. The socket used to connect the installed equipment to the electrical power supply must be within reach: otherwise, install a mains switch to disconnect the hood when required.

Any changes to the electrical system must be carried out by a qualified electrician.

The maximum length of the flue fastening screws (supplied by the manufacturer) must be 13 mm. Use of non-compliant screws with these instructions can lead to danger of an electrical nature.

Do not try to solve the problem yourself in the event of equipment malfunction, but contact the Dealer or an authorised Servicing Department for repairs.

 **When installing the hood, disconnect the equipment by removing the plug or switching off the main switch.**

FUMES DISCHARGE SAFETY

 **Do no connect the equipment to discharge pipes of fumes produced from combustion (for example boilers, fireplaces, etc.).**

Before installing the hood, ensure that all standards in force regarding discharge of air out of the room have been complied with.

Deviation for Australia and New Zeland: Range hoods and other cooking fume extractors may adversely affect the safe operation of appliances burning gas or other fuels (including those in other rooms) due to back flow of combustion gases. These gases can potentially result in carbon monoxide poisoning. After installation of a range hood or other cooking fume extractor, the operation of flued gas appliances should be tested by a competent person to ensure that back flow of combustion gases does not occur. (AS/NZS 60335.2.31:2013/A4:2020).

USER WARNINGS

 **These warnings have been drawn up for your personal safety and those of others. You are therefore kindly asked to read the booklet carefully in its entirety before using the or cleaning the equipment.**

The Manufacturer declines all responsibility for any damage caused directly, or indirectly, to persons, things and pets as a consequence of failing to comply with the safety warnings indicated in this booklet.

It is imperative that this instructions booklet is kept together with the equipment for any future consultation.

If the equipment is sold or transferred to another person, make sure that the booklet is also supplied so that the new user can be made aware of the hood's operation and relative warnings.

After the stainless steel hood has been installed, it will need to be cleaned to remove any residues remaining from the protection adhesive as well as any grease and oil stains which, if not removed, can cause irreversible damage to the hood surface. To properly clean the unit, the manufacturer recommends using the supplied moist wipes, which are also available sold separately.

Insist on original spare parts.

INTENDED USE

The equipment is solely intended to be used to extract fumes generated from cooking food in non-professional domestic kitchens: any other use is improper. Improper use can cause damage to persons, things, pets and exempts the Manufacturer from any liability.

The equipment can be used by children over the age of 8 and by persons with reduced physical, sensory and mental abilities, or with no experience or knowledge, as long as they do so under supervision or after having received relative instructions regarding safe use of the equipment and understanding of the dangers connected to it.

Children are not to play with the equipment. Cleaning and maintenance by the user must not be carried out by children without supervision.

USE AND CLEANING WARNINGS

 **Before cleaning or carrying out maintenance operations, disconnect the equipment by removing the plug or switching off the main switch.**

Do not use the hood with wet hands or bare feet. Always check that all electrical parts (lights, extractor fan) are off when the equipment is not being used. The maximum overall weight of any objects placed or hung (if applicable) on the hood must not exceed 1.5 Kg.

Always supervise the cooking process during the use of deep-fryers: Overheated oil can catch fire.

Do not leave open, unattended flames under the hood.

Do not prepare food over an open flame under the hood.

Never use the hood without the metal anti-grease filters: in this case, grease and dirt will deposit in the equipment and compromise its operation.

Accessible parts of the hood can be hot when used at the same time as the cooking appliances.

Do not carry out any cleaning operations when parts

of the hood are still hot.

There can be a risk of fire if cleaning is not carried out according to the instructions and products indicated in this booklet.

Disconnect the main switch when the equipment is not used for long periods of time.



If other appliances that use gas or other fuels are being used at the same time (boiler, stove, fireplaces, etc.), make sure the room where the fumes are discharged is well-ventilated, in compliance with the local regulations.

INSTALLATION

only intended for qualified personnel



Before installing the hood, carefully read the chapter 'SAFETY INSTRUCTIONS AND WARNINGS'.

TECHNICAL FEATURES

The technical specifications are exhibited on the labels located inside the hood.

POSITIONING

The minimum distance between the highest part of the cooking equipment and the lowest part of the hood is indicated in the installation instructions.

Generally, when the hood is placed over gas cookers, the distance must be at least 65 cm (25.6"). However, according to standard EN60335-2-31, the minimum distance between the cooker and lower part of the hood can be reduced to the quota reported in the installation instructions.

Should the instructions for the gas cooker specify a greater distance, this must be taken into consideration.

Do not install the hood outdoors and do not expose it to outdoor environment (rain, wind, etc.).

ELECTRICAL CONNECTION

(only intended for qualified personnel)



Disconnect the equipment from electrical mains power supply before carrying out any operations on the hood.

Ensure that the wires inside the hood are not disconnected or cut: in the event of damage, contact your nearest Servicing Department. Refer to qualified personnel for electrical connections.

Connection must be carried out in compliance with the provisions of law in force.

Before connecting the hood to the electrical mains power supply, check that:

- voltage supply corresponds with what is reported on the data plate located inside the hood;
- the electrical system is compliant and can withstand the load (see the technical specifications located inside the hood);
- the power supply plug and cable do not come into contact with temperatures exceeding 70 °C;
- the power supply system is effectively and properly connected to earth in compliance with regulations in force;
- the socket used to connect the hood is within reach.

In case of:

- devices fitted with cables without a plug: the type of plug to use is a "standardised" one. The wires must be connected as follows: yellow-green for earthing, blue for neutral and brown for the phase. The plug must be connected to an adequate safety socket.
- fixed equipment not provided with a power supply cable and plug, or any other device that ensures disconnection from the electrical mains, with an opening gap of the contacts that enables total disconnection in overvoltage category III conditions.

Said disconnection devices must be provided in the mains power supply in compliance with installation regulations.

The yellow/green earth cable must not be cut off by the switch.

The Manufacturer declines all responsibility for failure to comply with the safety regulations.

FUMES DISCHARGE

EXTERNAL EXHAUST HOOD (SUCTION)



In this version the fumes and vapours are discharged outside through the exhaust pipe.
To this end, the hood outlet fitting must be connected via a pipe, to an external output.

The outlet pipe must have:

- a diameter not less than that of the hood fitting.
- a slight slope downwards (drop) in the horizontal sections to prevent condensation from flowing back into the motor.
- the minimum required number of bends.
- the minimum required length to avoid vibrations and reduce the suction performance of the hood.

You are required to insulate the pipes if it passes through cold environments.
In the presence of motors with 800m³/h or higher, a check valve is present to prevent external air flowing back.

Deviation for Germany:

when the kitchen hood is used at the same time as appliances that are powered by energy other than electricity, the negative pressure in the room must not exceed 4 Pa (4 x 10⁻⁵ bar).

HOOD WITH INTERNAL RECIRCULATION (FILTERING)



In this model, the air passes through an optional filter unit in the ceiling to be purified and recycled in the environment.



In this version the check valve must not be assembled: remove it if it is on the air outlet fitting of the motor.

ASSEMBLY INSTRUCTIONS

only intended for qualified personnel



The hood can be installed in various configurations.
The generic assembly steps apply to all installations; for each case, follow the specific steps provided for the required installation.

OPERATION

WHEN TO TURN ON THE HOOD?

Switch on the hood at least one minute before starting to cook to direct fumes and vapours towards the suction surface.

After cooking, leave the hood operating until complete extraction of all vapours and odours. By means of the Timer function, it is possible to set auto switch-off function which will allow the hood to turn off automatically after 15 minutes of operation.

WHICH SPEED IS TO BE SELECTED?

1st speed: maintains the circulation of clean air with low electricity consumption.

2nd speed: normal conditions of use.

3rd speed: presence of strong odours and vapours.

4th speed: rapid disposal of odours and vapours.

WHEN SHOULD THE FILTERS BE WASHED OR REPLACED?

The metal filters must be cleaned every 30 hours of operation.

For further details see the **"MAINTENANCE"** chap.

TOUCH PUSHBUTTON PANEL



	ON/OFF (Blue led steady on) Motor on/off and Speed 1
	ON/OFF (blue led flashing) If pressed for more than 3 seconds, it activates the 24h cycle (1h ON -> 3h OFF -> 1h ON) the function deactivates if: - The motor turns off (key ) - After 24h
	Speed 2 activation
	Speed 3 activation
	Speed 4 activation for a few minutes only
	Light on/off
	TIMER (Red LED flashing) Auto switch-off after 15 min. The function deactivates (red LED off) if: - The motor turns off (key ) - The speed is changed.
	FILTER ALARM (red LED steady on) Anti-grease filter maintenance after approximately 30 hours of operation. Press the meter for 3 seconds to reset.



If the pushbutton panel is completely inactive, before contacting the Technical assistance service, disconnect power temporarily to the appliance (about 5"), possibly by acting on the main switch, to restore normal operation.

If this measure has no effect, contact the Technical assistance service.

MAINTENANCE



Before cleaning or carrying out maintenance operations, disconnect the equipment by removing the plug or switching off the main switch.

Do not use detergents containing abrasive, acidic or corrosive substances or abrasive cloths.

Regular maintenance guarantees proper operation and performance over time. Special attention is to be paid to the **metal anti-grease filters**: frequent cleaning of the filters and their supports ensures that no flammable grease is accumulated.

CLEANING OF EXTERNAL SURFACES

You are advised to clean the external surfaces of the hood **at least once every 15 days** to prevent oily substances and grease from sticking to them. To clean the brushed stainless steel hood, the Manufacturer recommends using "Magic Steel" wipes.

Alternatively **and for all the other types of surfaces**, it can be cleaned using a damp cloth, slightly moistened with mild, liquid detergent or denatured alcohol. Complete cleaning by rinsing well and drying with soft cloths.



Do not use too much moisture or water around the push button control panel and lighting devices in order to prevent humidity from reaching electronic parts.

The glass panels can only be cleaned with specific, non-corrosive or non-abrasive detergents using a soft cloth.
The Manufacturer declines all responsibility for failure to comply with these instructions.

CLEANING OF INTERNAL SURFACES



Do not clean electrical parts, or parts related to the motor inside the hood, with liquids or solvents.

For the internal metal parts, see the previous paragraph.

METAL ANTI-GREASE FILTERS

It is advised to **frequently** wash the metal filters (**at least once a month**) leaving them to soak in boiling water and cleaning solution for 1 hour, taking care not to bend them.

Do not use corrosive, acid or alkaline detergents.

Rinse them well and wait for them to be completely dry before reassembling them.

Washing in a dishwasher is permitted, however, it may cause the filter material to darken: to reduce the possibility of this problem from happening, use low-temperature washes (55°C max.).

To extract and insert the metal anti-grease filters see the assembly instructions.

LIGHTING

The hood has fluorescent lamp lighting.

If the lamp ever needs to be replaced, proceed as shown in the figure 9.

DISPOSAL AFTER END OF USEFUL LIFE



The crossed-out trash or refuse bin symbol on the appliance means that **the product is WEEE**, i.e. "Waste electrical and electronic equipment", accordingly **it must not be disposed of with regular unsorted waste** (i.e. with "mixed household waste"), but it must be disposed of separately so that it can undergo specific processing for its re-use, or a specific treatment, to remove and safely dispose of any substances that may be harmful to the environment and remove the raw materials that can be recycled. Proper disposal of these products contributes to saving valuable resources and avoid potential negative effects on personal health and the environment, which may be caused by inappropriate disposal of waste.

You are kindly asked to contact your local authorities for further information regarding the designated waste collection points nearest to you. Penalties for improper disposal of such waste can be applied in compliance with national regulations.

INFORMATION ON DISPOSAL IN EUROPEAN UNION COUNTRIES

The EU WEEE Directive was implemented differently in each country, accordingly, if you wish to dispose of this appliance we suggest contacting your local authorities or dealer to find out what the correct method of disposal is.

INFORMATION ON DISPOSAL IN NON-EUROPEAN UNION COUNTRIES

The crossed-out trash or refuse bin symbol is only valid in the European Union: if you wish to dispose of this appliance in other countries, we suggest contacting your local authorities or dealer to find out what the correct method of disposal is.



WARNING!

The Manufacturer reserves the right to make changes to the equipment at any time and without prior notice. Printing, translation and reproduction, even partial, of this manual are bound by the Manufacturer's authorisation.

Technical information, graphic representations and specifications in this manual are for information purposes and cannot be divulged.

This manual is written in Italian. The Manufacturer is not responsible for any transcription or translation errors.