
**USER MANUAL** 



# **WASHING MACHINE**

# **Front Loading**



# Read This Manual 🛄

Read all instructions and explanations for the installation before use. Follow the instructions carefully. Keep the operation instructions handy for later use. If the appliance is sold or passed on, ensure that the new owner always receives this operation instructions.

MODEL: MF200W70WB Series

MF200W80WB Series MF200W90WB Series MF200W100WB Series MF200W120WB Series

### Congratulations to your new machine!

This user manual will help you discover all the benefits of your machine and use it the way you want.

We strongly recommend that you read this manual carefully before using the washing machine for the first time. It contains important safety instructions and information relating to the installation, operation and maintenance. Proper handling contributes to efficient, environmentally friendly and safe use and minimises energy consumption during operation. Please always keep the proof of purchase to preserve any warranty claims.

# This manual includes instructions for setting up your SmartHome App "MSmartHome" as well.

These instructions for use are in general terms. This means: Certain functions apply to your machine, while others do not. We are continuously working on the further development and improvement of our unit types and models. Therefore, we reserve the right to make changes to the design, features and accessories of all types and models without prior notice.

On our website **www.midea.com** you can also download the user manual in digital form and discover other products. We hope you enjoy using your machine.

# **Explanation of symbols**



### Danger

This symbol indicates that there are dangers to the life and health of persons due to extremely fammable gas.



### Warning of electrical voltage

This symbol indicates that there is a danger to life and health of persons due to voltage.



### Warning

The signal word indicates a hazard with a medium level of risk which, if not avoided, may result in death or serious injury.



### Caution

The signal word indicates a hazard with a low degree of risk which, if not avoided, may result in minor or moderate injury.



### Notice

The signal word indicates important information (e.g. damage to property), but not danger.



### **Observe instructions**

Notes with this symbol indicate that you should read the operating instructions carefully.



### Observe instructions

This symbol indicates that a service technician should only operate and maintain this appliance in accordance with the operating instructions.

# **CONTENTS**

1	SA	FETY INSTRUCTIONS3	4 MAI	NTENANCE37
	1.1	Safety Instructions3	4.1	Cleaning and Care37
				Cleaning the Cabinet37
2	INS	<b>STALLATION</b> 11		Cleaning the Drum37
	2.1	Product Description <sub>11</sub>		Cleaning the Door Seal and Glass 37
		Accessories 11		Cleaning the Inlet Filter38
	2.2	Installation12		Cleaning the Detergent Dispenser39
		Installation area 12		Cleaning the Drain Pump Filter40
		Unpacking the machine <sub>13</sub>		Emergency Door Release41
		Remove transport bolts <sub>13</sub>	4.2	Trouble Shooting42
		Levelling the machine14	4.3	Customer service43
		Connect the water supply hose <sub>14</sub>		
		Drain Hose14	5 TEC	HNICAL SPECIFICATION44
		Acoustic Sponge15		
			6 PRO	DUCT FICHE45
3	OP	<b>PERATION</b> 16		
	3.1	Quick Start16	7 SMA	RT FUNCTION51
		Calibration16		
	3.2	Before Each Washing19		
	3.3	Detergent Dispenser20		
		Detergent Recommendation 21		
	3.4	Control Panel22		
	3.5	Display 23		
	3.6	Programmes24		
	3.7	Option33		

# INTENDED USE

The product is intended only for home use and for textiles in household amounts suitable for washing. This appliance is for indoor use only and not intended for built in use. Only use according to these instructions. The appliance is not intended for commercial use.

Any other use is considered as improper use. The producer is not responsible for any damage or injuries that may result of it.

- This appliance is intended to be used in household and similar applications such as:
- Staff kitchen areas in shops, offices and other working environments;
- Farm houses;
- By clients in hotels, motels and other residential type environments;
- Bed and breakfast type environments;
- Areas for communal use in blocks of flats or in launderettes.

# ■ 1.1 Safety Instructions

Please read the following safety information thoroughly and follow it strictly to minimize the risk of fire or explosion, electric shock and to prevent property damage, personal injury or loss of life. Failing to follow these instructions shall void any warranty.

# /!\ Warning!

This combination of symbol and signal word indicates a potentially dangerous situation which may result in death or serious injuries unless it's avoided.



# ↑ Caution! -

This combination of symbol and signal word indicates a potentially dangerous situation which may result in slight or minor injuries or damage to property and the environment.

# Note!

This combination of symbol and signal word indicates a potentially dangerous situation which may result in slight or minor injuries.

# 

# **ELECTRIC SHOCK HAZARD**

- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- If the machine is damaged, it must not be operated unless repaired by the manufacturer, its service agent or similarly qualified persons.
- Risk of electric shock!
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children should be supervised that they do not play with the appliance.
- Children 3 years and under shall be kept away from the appliance or continuously supervised.
- Animals and children may climb into the machine. Check the machine before every operation.
- Do not climb or sit on the appliance.

# INSTALLATION LOCATION AND SURROUNDING

- All washing and additional substances are to be kept in a safe place out of the reach of children.
- Do not install the machine on a carpet floor.
- The obstruction of the openings by a carpet can damage the machine.
- •Keep the appliance clear from heating sources and direct sunlight to avoid plastic and rubber parts to corrode.
- •Do not use the appliance in humid environments or rooms containing explosive or caustic gas. In case of water leakage or water splashes let the appliance dry in the open air.
- The appliance must not be installed behind a lockable door, a sliding door or a door with a hinge on the opposite side to that of the washing machine.
- Do not operate the machine in rooms with a temperature of below 5°C. This can cause damages to parts of it. If it is unavoidable, make sure to drain the water completely from the appliance after every use (see "Maintenance Cleaning of drain pump filter") to avoid damages caused by frost.
- Never use flammable sprays or substances in the immediate proximity of the appliance.

# INSTALLATION

- Remove all packaging material and transport bolts before using the appliance. Otherwise, serious damage may result.
- This appliance is equipped with a single inlet valve and can be connected to the cold water supply only.
- Mains plug must be accessible after installation.
- •Before washing clothes for the first time, the product shall be operated once throughout all the procedures without any clothes inside. Before using the washing machine, the product shall be calibrated.
- Do not put any excessively heavy objects on the appliance, like water containers or heating devices.
- •The new hose-sets supplied with the appliance are to be used and that old hose-sets should not be reused.
- Max. Inlet water pressure 1 MPa. Min. inlet water pressure 0.05 MPa.

# **ELECTRICAL CONNECTION**

- Make sure the supply cable is not trapped by the machine, it can get damaged.
- •Connect the product to a grounded outlet protected by a fuse complying with the values in the "Technical specifications" table. The grounding installation has to be made by a qualified electrician. Ensure that the machine is installed in accordance with the local

regulations.

 Water and electrical connections must be carried out by a qualified technician in accordance with the manufacturer's instructions and local safety regulations.

# 

- Don't use multiple plugs or extension cords.
- •The appliance must not have an external switching device such as a timer or connected to a circuit that is regularly switched on and off.
- •Do not pull the plug out of the mains outlet if there is flammable gas around.
- •Never pull out power plug with wet hands.
- Always pull at the plug, not at the cable.
- Always unplug the appliance if it is not being used.

# WATER CONNECTIONS

- Check the connections of the water inlet tubes. the water tap and the outlet hose for possible problems due to changes of water pressure. If the connections loosen or leak, close the water tap and get it repaired.
- Do not use the appliance before the pipes and hoses are installed properly by qualified persons.
- Glass door may become very hot during the operation. Keep children and pets far away from the machine while it is operating. The water inlet and outlet hoses have to be safely installed and remain undamaged.
- Otherwise, water leakage can occur.

 Do not remove the drain pump filter while there is still water in the appliance. Big quantities of water can leak out, and there is a risk of scalding due to hot water.

# **OPERATION AND MAINTENANCE**

- Never use any flammable, explosive or toxic solvents. Do not use gasoline and alcohol etc. as detergents. Only select detergents that are suitable for machine washing.
- Make sure that all pockets are emptied. Sharp and rigid items such as coins, brooches, nails, screws, stones etc. may cause serious damages to this machine.
- Remove all objects from pockets such as lighters and matches before use the appliance. Thoroughly rinse items that have been washed by hand.
- Items that have been soiled with substances such as cooking oil, acetone, alcohol, petrol, kerosene, spot removers, turpentine, wax and wax removers should be washed in hot with an extra amount of detergent before being dried in the appliance.
- Items containing foam rubber (latex foam), shower caps, water proof textiles, rubber backed articles and clothes or pillows fitted with foam rubber pads should not be washed in the machine.
- Fabric softeners or similar products should be used are recommended in their instructions.
   Never try to open the door forcefully.

- The door will unlock shortly after the end of a cycle.
- Please do not close the door with excessive force. If it is found difficult to close the door, please check if the clothes are properly inserted and distributed.
- Always unplug the appliance and close the
- water tap before cleaning and maintenance and after each use.
- Never pour water over the appliance for cleaning purpose. Risk of electric shock!
- Repairs shall only be carried out by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The producer will not be responsible for damages caused by the intervention of not authorized persons.

# **TRANSPORT**

- •Before Transport:
  - -Bolts shall be reinstalled to the machine by a specialized person;
  - -Accumulated water shall be drained out of the machine.
- •This appliance is heavy. Transport with care. Never hold any protruding part of the machine when lifting. The machine door can not be used as a handle.

# **ENVIRONMENT**

Disposal of old appliances (Only for EU countries)

This appliance is labelled in accordance with the European Directive 2012/19/EU on waste electrical and electronic equipment (WEEE). The directive provides the framework for the EU-wide take-back and recycling of waste equipment.




# The devices marked with this symbol must not be disposed of in household waste!


As a manufacturer, we ensure environmentally friendly treatment and recycling of old appliances within the scope of product responsibility. Our products are registered with the authorities for electrical appliances and packaging. For further information on collection and disposal, please contact your local authority, city council or your

(specialised) retailer. Already during the development of new appliances, we pay attention to a high recyclability of the materials used. High recycling rates are achieved via the take-back system to reduce the burden on waste dumps and the environment. Together, we are making an important contribution to environmental protection.

# 2 INSTALLATION

# ■ 2.1 Product Description





	Service	flap
v	Jei vice	Hap

2 Door

3 Detergent dispenser

4	Control	pane
---	---------	------


5 Drain hose

6 Power supply cord

# Note!-

• The product picture is for illustration only, please refer to real product as reference.

### Accessories



4 x Cover caps

1 x Supply hose cold water

1 x Owner's manual

Acoustic sponge (optional)

# 2 INSTALLATION

# ■ 2.2 Installation

# Tools Needed If Installation By Yourself (not include)















### Installation area

# / Warning!

- Stability is important to prevent the product from wandering!
- Make sure the machine is standing leveled and stable.
- Make sure that the product does not stand onto the power cord.
- Make sure to maintain the minimum distances from the walls as shown in the picture.






Before installing the machine, the location characterized as follows shall be selected:

- 1. Rigid, dry, and level surface.
- 2. Avoid direct sunlight.
- 3. Sufficient ventilation.
- 4.Room temperature is above 5°C.
- 5. Keep far away from the heat sources such as coal or gas burning appliances.

### Unpacking the machine



# **!** Warning!

- Packaging material (e.g. Films, Styrofoam) can be dangerous for children.
- There is a risk of suffocation! Keep all packaging well away from children.
- 1. Remove the cardboard box and styrofoam packing.
- 2. Lift the washing machine and remove the base packaging. Make sure the small triangle foam (a) is removed with the bottom packaging together. If not, lay the unit down on the side surface and remove it manually.
- 3. Remove the tape securing the power supply cord and drain hose.
- 4. Remove the inlet hose from the drum.


# **Remove transport bolts**

# **!** Warning! –

 You must remove the transport bolts from the backside before using the product.



Loosen the 4 transport bolts with a spanner.



Remove the bolts including the rubber parts and keep them for future use.



Close the holes using the cover caps.

# 2 INSTALLATION

### Levelling the machine



• The lock nuts on all four feet must be screwed tightly against the housing.



- 1. Loosen the lock nut.
- 2. Turn the foot until it reaches the floor.
- 3. Adjust the legs and lock the nuts with a spanner. Make sure the machine is level using a spirit level.

### Connect the water supply hose


# **№** Warning! ——

To prevent leakage or water damage, follow the instructions in this chapter.

• Do not kink, crush or modify water inlet hose.



Connect the water supply hose to the water inlet valve and a water tap with cold water as indicated.



# Note!

• Connect manually, do not use tools. Check if the connections are tight.


### **Drain Hose**




- Do not kink or protract the drain hose.
- Position drain hose properly ,otherwise damage might result of water leakage.
- It is not allowed to remove the buckle of drain pipe.

# 2 INSTALLATION

There are two ways to place the end of drain hose:



1.Put it into the water trough.





2.Connect it to the branch drain pipe of the trough.

### **Acoustic Sponge**

# Note!

Please make sure to assemble the acoustic sponges, which can
effectively reduce the noise caused by the machine while working,
in order to provide you with a more peaceful and quiet living
environment.





- Get the machine laid on the floor, using some soft material like foam or clothes between the machine and floor for a protection.
- 2. Stick the 2x longer sponges to the longer bottom edges of machine, and the 2x shorter sponges to the shorter bottom edges.

# 3.1 Quick Start

### Caution!


- Before washing, please make sure the washing machine is installed properly.
- Your appliance was thoroughly checked before it left the factory. To remove any residual water and to neutralize potential odors, it's recommended to clean your appliance before first use. For this reason, start the Cotton program at 90°C without laundry and detergent.

### Calibration

It's recommended to calibrate the washing machine, so that provide the best performance.


The appliance is able to detect the amount of laundry loaded. This function is optimizing the product performance by minimizing energy and water consumption, saving you money and time. For this reason it's recommended to calibrate the appliance for best use.

- 1. Remove all accessories from the drum and close the door;
- 2. Insert the mains plug to the socket;
- 3. Switch on the washing machine, and within10 seconds, press "Turbo" and "Extra Rinse" simultaneously and continuously (normally 3 seconds) until "t19" is displayed on the knob.




4. Press | to start the appliance, initially"---" is displayed, and then "\*\*\*" (such as "126") is displayed to indicate the real time drum speed. When the number reaches a certain value (stop changing), it means the washing machine is successfully calibrated.

# 1. Before Washing







Plug in

Open tap

Load





Close door


Add detergent




# Note! -

• Detergent need to be added in compartment I if the pre-wash function is selected.


# 2. Washing




Power on



Select programme



Select function or remain default settings




Press Start/Pause to start the program

# 3. After Washing


Buzzer beep and "End" on display.

# ■ 3.2 Before Each Washing


- The ambient temperature of the machine should be 5°C-40°C. If used under 0°C, the inlet valve and draining system may be damaged. If the machine is installed under freezing conditions, it should be transferred to normal ambient temperature to ensure the water supply hose and drain hose can unfreeze before use.
- Please check your laundry care labels and the detergent use instructions before wash. Use non-foaming or less-foaming detergent suitable for washing machine properly.



Take all items out of the pockets



Tie together long textile strips and belts, close zips and button



Sort laundry according to color and textile type




Put small items into a laundry bag

# / Warning!

- Do not wash articles that have been cleaned in, washed in, soaked in, or dabbed with combustible or explosive substances like wax, oil, paint, gasoline, alcohol, kerosene, and other flammable materials.
- Washing single clothes items may easily create big eccentricity.
   Therefore it is suggested to add one or two more laundry items to the wash so that spin can be done smoothly.

# ■ 3.3 Detergent Dispenser

- Pre wash
- 11 Main wash
- ⊗ Softener
- Release button to pull out the dispenser





# **!**\ Caution!-

Detergent only need to be added in "compartment I "after selecting pre-wash function.

Programme		/0	₩	Programme		/0	₩
Cotton	0	•	0	Rapid 45'	0	•	0
Mix	0		0	ECO 40-60			0
Synthetic	0		0	Bullky	0		0
Jeans	0	•	0	Wool		•	0
20℃			0	Rinse & Spin			0
Allergy Care	0	•	0	Spin Only			
Steam Care	0		0	Drum Clean			
Quick 15'		•	0				

- Means mustMeans optional

# **Detergent Recommendation**

Recommended washing detergent	Type of laundry and textile	Wash cycles	Washing temp.
Heavy-duty detergent with bleaching agents and optical brighteners	White laundry made from boil-proof cotton or linen	Cotton,ECO 40-60, Mix,Bulky	20/30/ 40/60
Colour detergent without bleaching agent and optical brighteners	Coloured laundry made from cotton or linen	Cotton, ECO40-60, Mix, Bulky, 20°C	Cold/20 /30/40
Color or mild detergent without optical brighteners	Coloured laundry made from easy care fibres or synthetic materials	20°C,Synthetic	Cold/20/ 30/40
Mild washing detergent	Delicate textiles, silk, viscose	Synthetic	20 /30
Special wool detergent	Wool	Wool	20/30

# Note!

- Agglomerating or ropy detergent or additive can be diluted in some water before pouring it into the detergent dispenser, to avoid its inlet to get blocked and thus cause a water overflow.
- Please choose the suitable type of detergent to get a maximum of washing performance and a minimum of water and energy consumption.
- To achieve the best cleaning result a proper detergent dosing is important.
- Use a reduced detergent amount if the drum is not filled completely.
- Always adjust the amount of detergent to the water hardness, if your tap water is soft, use less detergent.
- Dose according to how dirty your laundry is, less dirty clothes require less detergent.
- Highly concentrated (compact detergent) requires particularly accurate dosing.


Following symptoms are a sign of detergent overdosing:

- heavy foam formation
- poor washing and rinsing result

Following symptoms are a sign of detergent underdosing:

- laundry turns grey
- built-up of limescale deposits on the drum, the heating element and/or the laundry

# 3.4 Control Panel



# Display

The display shows settings, estimated remaining time, options and status messages.

# 2 Option

Press buttons to change program parameters or select additional functions.

# 3 On/Off

Power on or off machine.


# 4 Start/Pause

Start or pause your program.

# 5 Program

Choose appropriate program according to the laundry type.

# ■ 3.5 Display



# A Display

<b>B</b> WiFi	Remote Control
Delay	Door Lock
<b>⊕</b> Child Lock	<b>⊙</b> SteamCare
AutoClean	PreWash
• Wash	Rinse

Spin

# **■ 3.6 Programmes**

Programmes are available according to the laundry type.

Programmes	
Cotton	Hard-wearing textiles, heat-resistant textiles made of cotton or linen.
Mix	Mixed load consisting of textiles made of cotton and synthetics.
Synthetic	Wash synthetic articles, for example: shirts, coats, blending. While washing the knitting textiles, detergent quantity shall be reduced due to its loose string construction and easily forming bubbles.
Jeans	Specially for jeans.
20℃	Washing brightly colored clothes, it can protect the colors better.
Allergy Care	This program applies 60°C high temperature sterilization to make the clothes washing more clean to achieve the anti-allergy effect.
Steam Care	Steam Care is applicable for daily laundries like cotton and synthetics. The steam can deeply penetrate the fiber, which effectively eliminate bacterias and germs, preventing odors and protecting your health.
Quick 15'	Extra short program approx, suitable for lightly soiled washing as a small amounts of laundry.
Rapid 45'	This program is suitable for washing not very dirty clothes, save more energy and washing.
ECO 40-60	Default 40°C,not selectable,suitabale for laundry washing at about 40°C-60°C.
Bulky	This program is specially designed for washing duvet coats.
Wool	Hand or machine-washable wool or richwool textiles. Especially gentle wash program to prevent shrinkage, longer program pauses (textiles rest in wash liquor).
Rinse&Spin Spin Only	Extra rinse with spin. Extra spin with selectable spin speed.

# Drum Clean Specially set in this machine to clean the drum and tube. It applys 90 °C high temperature sterilization to make the clothes washing more green. When this programme is performed, the clothes or other washing cannot be added. When proper amount of chlorine bleaching agent is put in, the barrel cleaning effect will be better. The customer can use this programme regularly according to the need.

Programme	Load(kg)				Display Time					
	7.0	8.0	9.0	10.0	12.0	7.0	8.0	9.0	10.0	12.0
Cotton	7.0	8.0	9.0	10.0	12.0	3:49	3:49	3:49	3:49	3:49
Mix	7.0	8.0	9.0	10.0	12.0	1:30	1:30	1:30	1:30	1:30
Synthetic	3.5	4.0	4.5	5.0	6.0	3:27	3:27	3:27	3:27	3:27
Jeans	7.0	8.0	9.0	10.0	12.0	1:46	1:46	1:46	1:46	1:46
20°C	3.5	4.0	4.5	5.0	6.0	1:01	1:01	1:01	1:01	1:01
Allergy Care	3.5	4.0	4.5	5.0	6.0	2:38	2:38	2:38	2:38	2:38
Steam Care	3.5	4.0	4.5	5.0	6.0	1:57	1:57	1:57	1:57	1:57
Quick 15'	2.0	2.0	2.0	2.0	2.0	0:15	0:15	0:15	0:15	0:15
Rapid 45'	2.0	2.0	2.0	2.0	2.0	0:45	0:45	0:45	0:45	0:45
ECO 40-60	7.0	8.0	9.0	10.0	12.0	3:28	3:38	3:48	3:59	4:00
Bulky	7.0	8.0	9.0	10.0	12.0	1:48	1:48	1:48	1:48	1:48
Wool	2.0	2.0	2.0	2.0	2.0	1:07	1:07	1:07	1:07	1:07
Rinse & Spin	7.0	8.0	9.0	10.0	12.0	0:20	0:20	0:20	0:20	0:20
Spin Only	7.0	8.0	9.0	10.0	12.0	0:12	0:12	0:12	0:12	0:12
Drum Clean	-	-	-	-	-	1:18	1:18	1:18	1:18	1:18

### MF200W70WB Series

Cycle	Nominal capacity in kg	Temperature setting	Cycle duration in h:min	Energy consumption in kWh/cycle	Water consumption in L/cycle	Highest washing temperature °C <sup>n</sup>	Residual moisture in % / Spin speed <sup>2)</sup>
Bulky	7.0	40	1:48	0.661	65	40	65%/1000
20°C	3.5	20	1:01	0.175	41	20	65%/1000
Cotton(60°C)	7.0	60	3:54	1.315	65	60	65%/1000
Mix	7.0	40	1:30	0.661	65	40	70%/800
Quick 15'	2.0	Cold	0:15	0.03	40	Cold	70%/800
	7.0	_	3:28	0.778	53.5	40	53.9%/1350
ECO 40-60 <sup>3)</sup>	3.5	_	2:42	0.437	45.6	32	53.9%/1350
	2.0	-	2:42	0.230	34.2	28	53.9%/1350

- The above data is for reference only, and the data may change due to different actual use conditions.
- The values given for programmes other than the ECO 40-60 programme are indicative only.
- Concerning to EN 60456:2016+A11:2020 With(EU) 2019/2014,
   (EU) 2019/2023, (EU) 2021/340, (EU) 2021/341,

The EU energy efficiency class is: B

Energy test program: ECO 40-60. Other as the default.

Half load for 7.0kg machine: 3.5kg.

Quarter load for 7.0kg machine: 2.0kg.

### MF200W80WB Series

Cycle	Nominal capacity in kg	Temperature setting	Cycle duration in h:min	Energy consumption in kWh/cycle	Water consumption in L/cycle	Highest washing temperature °C"	Residual moisture in % / Spin speed <sup>2)</sup>
Bulky	8.0	40	1:48	0.803	71	40	65%/1000
20°C	4.0	20	1:01	0.183	44	20	65%/1000
Cotton(60°C)	8.0	60	3:54	1.506	71	60	65%/1000
Mix	8.0	40	1:30	0.772	71	40	70%/800
Quick 15'	2.0	Cold	0:15	0.03	31	Cold	70%/800
	8.0	-	3:38	0.770	59	37	53.9%/1350
ECO 40-60 <sup>3)</sup>	4.0	-	2:48	0.415	45	31	53.9%/1350
	2.0	_	2:48	0.194	37	22	53.9%/1350

- The above data is for reference only, and the data may change due to different actual use conditions.
- The values given for programmes other than the ECO 40-60 programme are indicative only.
- Concerning to EN 60456:2016+A11:2020 With(EU) 2019/2014,
   (EU) 2019/2023, (EU) 2021/340, (EU) 2021/341,

The EU energy efficiency class is: A

Energy test program: ECO 40-60. Other as the default.

Half load for 8.0kg machine: 4.0kg. Quarter load for 8.0kg machine: 2.0kg.

### MF200W90WB Series

Cycle	Nominal capacity in kg	Temperature setting	Cycle duration in h:min	Energy consumption in kWh/cycle	Water consumption in L/cycle	Highest washing temperature °C <sup>n</sup>	Residual moisture in % / Spin speed <sup>2</sup>
Bulky	9.0	40	1:48	0.862	78	40	65%/1000
20°C	4.5	20	1:01	0.189	48	20	65%/1000
Cotton(60°C)	9.0	60	3:54	1.620	78	60	60%/1200
Mix	9.0	40	1:30	0.813	78	40	70%/800
Quick 15′	2.0	Cold	0:15	0.030	31	Cold	70%/800
	9.0	-	3:48	0.821	66.5	39	53.9%/1300
ECO 40-60 <sup>3)</sup>	4.5	-	2:54	0.451	52.4	28	53.9%/1300
	2.5	-	2:54	0.245	35	22	53.9%/1300

- The above data is for reference only, and the data may change due to different actual use conditions.
- The values given for programmes other than the ECO 40-60 programme are indicative only.
- Concerning to EN 60456:2016+A11:2020 With(EU) 2019/2014,
   (EU) 2019/2023, (EU) 2021/340, (EU) 2021/341,

The EU energy efficiency class is: A

Energy test program: ECO 40-60. Other as the default.

Half load for 9.0kg machine:4.5kg. Quarter load for 9.0kg machine:2.5kg.

### MF200W100WB Series

Cycle	Nominal capacity in kg	Temperature setting	Cycle duration in h:min	Energy consumption in kWh/cycle	Water consumption in L/cycle	Highest washing temperature °C <sup>n</sup>	Residual moisture in % / Spin speed <sup>2</sup>
Bulky	10.0	40	1:48	0.920	85	40	65%/1000
20°C	5.0	20	1:01	0.195	51	20	65%/1000
Cotton(60°C)	10.0	60	3:54	1.726	85	60	60%/1200
Mix	10.0	40	1:30	0.871	85	40	70%/800
Quick 15′	2.0	Cold	0:15	0.030	31	Cold	70%/800
	10.0	-	3:59	0.885	72	35	53.9%/1350
ECO 40-60 <sup>3)</sup>	5.0	-	3:00	0.545	54	30	53.9%/1350
	2.5	_	3:00	0.247	38	22	53.9%/1350

- The above data is for reference only, and the data may change due to different actual use conditions.
- The values given for programmes other than the ECO 40-60 programme are indicative only.
- Concerning to EN 60456:2016+A11:2020 With(EU) 2019/2014,
   (EU) 2019/2023, (EU) 2021/340, (EU) 2021/341,

The EU energy efficiency class is: A

Energy test program: ECO 40-60. Other as the default.

Half load for 10.0kg machine:5.0kg.

Quarter load for 10.0kg machine: 2.5kg.

### MF200W120WB Series

Cycle	Nominal capacity in kg	Temperature setting	Cycle duration in h:min	Energy consumption in kWh/cycle	Water consumption in L/cycle	Highest washing temperature °C"	Residual moisture in % / Spin speed <sup>2)</sup>
Bulky	12.0	40	1:48	1.037	99	40	65%/1000
20°C	6.0	20	1:01	0.206	58	20	65%/1000
Cotton(60°C)	12.0	60	3:54	1.928	99	60	60%/1200
Mix	12.0	40	1:30	1.006	99	40	70%/800
Quick 15'	2.0	Cold	0:15	0.030	31	Cold	70%/800
	12.0	_	4:00	1.186	82	42	53.9%/1350
ECO 40-60 <sup>3)</sup>	6.0	_	3:00	0.618	58	30	53.9%/1350
	3.0	_	3:00	0.253	46	23	53.9%/1350

- The above data is for reference only, and the data may change due to different actual use conditions.
- The values given for programmes other than the ECO 40-60 programme are indicative only.
- Concerning to EN 60456:2016+A11:2020 With(EU) 2019/2014,
   (EU) 2019/2023, (EU) 2021/340, (EU) 2021/341,

The EU energy efficiency class is: A

Energy test program: ECO 40-60. Other as the default.

Half load for 12.0kg machine:6.0kg. Quarter load for 12.0kg machine:3.0kg.

- 1) The highest temperature reached by the laundry in the wash cycle for at least 5 minutes.
- 2) Residual moisture after the wash cycle in water content percent and the spin speed at which this was achieved.
- 3) The ECO 40-60 programme is able to clean normally soiled cotton laundry declared to be washable at 40°C or 60°C, together in the same cycle. This programme is used to assess the compliance with the regulation (EU) 2019/2014, (EU) 2019/2023, (EU)2021/340, (EU) 2021/341.

The most efficient programmes in terms of energy consumption are generally those that perform at lower temperatures and longer duration.

Loading the household machine up to the capacity indicated for the respective programmes will contribute to energy and water savings.

Noise and remaining moisture content are influenced by the spinning speed: the higher the spinning speed in the spinning phase, the higher the noise and the lower the remaining moisture content.



### Caution!

 If there is any break in the power supply while the machine is operating, a special memory stores the selected programme. The machine will continue the programme when the power supply is re-established.

# ■ 3.7 Option

Cycle	Default Temp.(°C)	Default spin speed	Additional functions
		1400	
Quick 15'	Cold	800	©,
Rapid 45'	40	800	©, U, 🖶,
ECO 40-60		1400	©,
Bulky	40	1000	©, ∪, ៉, ▶,
Wool	40	600	©, ₩,
Rinse & Spin		1000	©, 🖶 ,
Spin Only		1000	©,
Steam Care	40	800	ⓒ, ധ, ՝ ՝ , ��, ��,
Allergy Care	60	800	©, ௰, ఄ <b>֎</b> , �, ቆ,
20℃	20	1000	C, 🖶 ,
Jeans	30	1000	©, ∪, ៉ <b>, &gt;</b> , <b>?</b> ,
Synthetic	40	1200	©, ∪, ៉, >, %,
Mix	40	800	©, ∪, ៉∞, ▶, ở,
Cotton	40	1200	ⓒ, ٺ, ♚, ▶,❖,
Drum Clean	90		©,

# Note!

- For the maximum spin speed, program time, and other details of the ECO 40-60 program, please refer to the content on the Product Fiche page.
- The table shows which cycle offers which options for adjustment.

Spin

Spin

When needed, the spinning speed can be adjusted pressing the Speed button in the following steps:

1400: 0-400-600-800-1000-1200-1400.

**?** 

Remote Control

Turn on the WiFi function and control remotely by pressing the button for 3 seconds, please refer to the MSmartHome instructions for more information.

Ш

Pre Wash

Extra washing function before the main washing cycle starting to increase the washing performance.

Note: Detergent needs to be added to the detergent dispenser compartment I.

9

Wifi

Turn on the WiFi function and configure/reset the network by pressing the button for 3 seconds, please refer to the MSmartHome instructions for more information.

Temp.

Temp.

When needed, the washing temperature can be adjusted by pressing the temperature button in the following steps: Cold - 20°C - 30°C - 40°C - 60°C - 90°C.

You can also turn off the WiFi function by pressing the button for 3 seconds, please refer to the MSmartHome instructions for more information.



Note!

• The detail of connect WIFI, pls check "SMART FUNCTION".



### Child Lock

This function is meant to keep children from misusing the controls.



Press [3s for Child Lock] simultaneously for 3 sec until the buzzer beep. The child lock indicator switches on.



### ∕!\ Caution!

When the Child Lock is activated, the display will alternately show "CL" and the remaining time.

Pressing any other button will cause the Child Lock indicator to flash. When the program ends, "CL" and "END" will alternate on the display.

The Child Lock deactivates the function of all buttons except the On/Off button and the Child lock button!

Only the simultaneous pressing of the button [3s for Child Lock] can deactivate the Child Lock!

Please deactivate the Child Lock before selecting a new program!

Water Level

### Water Level

Press the button to change the water level: AU/L-1/L-2/L-3/L-4



### AutoClean

The Auto clean function will be automatically activated during every washing cycle. AutoClean Pro system will keep your laundry always clean. Environmentally save time and ease your laundry.



### SteamCare

SteamCare is the function added before main wash, which will generate warm steam to sterilization and greater washing performance.



### Caution!-

Some programs have automatically added AutoClean or SteamCare functions, these two functions can't be manually selected or canceled.

### **3 OPERATION**



### Reload

This operation can be executed during the washing progress.

When the drum is still rolling and there is large amount of water with high temperature in the drum.

The state is unsafe and the door cannot be opened forcefully. To Press[3s for Reload]3sec. to reload, and start the clothes adding in the midway function. Please follow the steps as bellow: 1.Wait until the drum stops rotation.

- 2.The door lock is unlocked.
- 3.Close the door when the clothes are reloaded and press the [Start/Pause] button.



Press[3s for Reload]3sec.

Reload the clothes

Start

Delay

### Delay

- 1. Select a program
- 2. Press the Delay button to choose the delaying time 0-24h
- 3.Press [Start/Pause] to start the delay operation



Choose program

Setting time

Start

To cancel the Delay function, press the "Delay" button before starting the program until the display shows 0 h. If the program has already started, switch the appliance off and afterwards on and select a new program.



#### Extra Rinse

The laundry will undergo an extra rinse after selecting this function.




#### Turbo

The function can decrease the washing time.



### Mute the buzzer



Start

Press the [Extra Rinse]button for 3sec.

to mute the buzzer.

To act the buzzer function, press the button again for 3 seconds. The setting will be kept until the next reset.

# ■ 4.1 Cleaning and Care

# /!\Warning! -

 Always unplug the appliance and close the water tap before cleaning and maintenance.

### **Cleaning the Cabinet**

Proper maintenance on the washing machine can extend its working life. The surface can be cleaned with diluted non-abrasive neutral detergents when necessary. If there is any water overflow, use a towel to wipe it off immediately.

Never use sharp items to clean the appliance.



#### Caution!

 Never use abrasive or caustic agents. formic acids or its diluted solvents or similar substances, like alcohol or chemical products.

### Cleaning the Drum

Any rust stains left inside the drum by metal articles must be removed immediately using chlorine-free detergents. Never use steel wool for cleaning the drum!



### Note! -

• Keep any laundry away from the machine while cleaning the drum.

### **Cleaning the Door Seal and Glass**

Wipe the glass and seal after each wash to remove lint and stains. If lint builds up it can cause leakages.


Remove any coins, buttons and other objects from the seal after each wash. Clean the Door Seal and Glass every month to ensure the normal operation of the appliance.




### Cleaning the Inlet Filter

### ♪ Note!—

• Diminishing water flow is a sign that the filter need to be cleaned.



1. Close the tap and remove the water supply hose from it.



2. Clean the filter with a brush.



3. Unscrew the water supply hose from the backside of the machine. Pull out the filter with long nose pliers.




4. Use a brush to clean the filter.

- 5. Reinstall the filter to the water inlet and reconnect the water supply hose.
- 6. Clean the Inlet filter every 3 months to ensure the normal operation of the appliance.

### **Cleaning the Detergent Dispenser**


- 2. Lift the softener cover off the dispenser drawer and wash both items with water.
- 3. Restore the softener cover and push the drawer back into the recess.




Press the release and remove the dispenser drawer



Clean the dispenser drawer and the softener cover under water



Clean the recess with an soft brush



Insert the dispenser drawer


### Note!

- Do not use abrasive or caustic agents to clean plastic parts.
- Clean the detergent dispenser every 3 months to ensure the normal operation of the appliance


### **Cleaning the Drain Pump Filter**

# **Warning!**

- Make sure that the machine has finished the washing cycle and is empty. Switch it off and unplug it before cleaning the drain pump filter.
- Be careful of hot water. Wait for water cooling down. Risk of scalding!
- Clean the filter periodically every 3 months to ensure the normal operation of the appliance.




Open the lower cover cap




Pull out the emergency drain hose, and take off the hose cap




After water runs out, reset the drain hose



Open the filter by turning to the counter clockwise



Remove extraneous matter



Carefully reinsert the filter and screw the lower cover cap in clockwise




### ∕!\ Caution! ·

- Make sure emergency drain hose cap and the emergency drain hose are reinstalled properly, otherwise water may leak.
- Some machine don't have emergency drain hose, so step 2 and step 3 can be skipped. Rotate lower cover cap directly to make water run into basin.


### **Emergency Door Release**

In case of power failure or other circumstances and door cannot be opened. If it is necessary to open the door under this circumstances, please pull down the pull cord inside emergency door and restore the pull cord after opening the door.


### Emergency door pull cord



1.Open filter door.



2.Using a straight screwdriver (or other non-sharp tool), insert into the emergency door pull cord.



3.Pull down the emergency door pull cord (refer to direction of the arrow in the picture). If unlocked successfully, you will find the door lock icon will go out.



The machine is not allowed to use the emergency switch pull cord during washing. If need to run machine urgently, it is recommended to open door after water is cooled, to avoid getting burn caused by high temperature residual water outflow from the machine tub.

# ■ 4.2 Trouble Shooting

Whenever there is a problem with the appliance, check if you can solve it following the tables below. If the problem persists, please contact the customer service.

Description	Possible cause	Solution
Appliance does not start	Door is not closed properly.Clothes are stuck.	Close the door properly andrestart. Check the laundry.
Door can't be opened	Safety protection is activated.	Disconnect the power and restart.
Water leakage	Connections are not tight enough.	Check and fasten the water inlet pipe.Check and clean the outlet hose.
Detergent residues in the detergent dispenser	Detergent is damp and/or clotted.	Clean and wipe the detergent dispenser dry.
Indicator or display does not work	PC board or harness have connection problems.	Switch off the power and check if the mains plug is connected properly.
Abnormal noise	Fixing bolts still in place. Floor is not solid or level.	Check if the fixing bolts have been removed.  Make sure the appliance is installed on a solid and level floor.

#### **Error Codes**

Description	Possible cause	Solution
E30	Door is not closed properly.	Close the door properly and restart.
E10	Water injecting problem during wash cycle.	Check if the water pressure is high enough. Straighten the water pipe. Clean the inlet valve filter.
E21	Overtime water draining	Check the drain hose for blockage.
E12	Water overflow	Restart the appliance.
EXX	Others	Restart the appliance. If problem persists, please contact the customer service

### 4.3 Customer service

Spare part for your appliance are available for a minimum of 10 years following EU COMMISSION REGULATION 2019/2023 ANNEX II Ecodesign requirements...

In case of questions, please contact our local customer service center.

# **∕!** Warning!

Risk of electric shock


- Never try repair an appliance which is defective of presumed to defective. You may put your own and future users' lives in danger.
   Only authorised specialists are allowed to carry out this repair work.
- Improper repair will void the warranty and subsequent damages can't be recognized!

### **Transport**

### IMPORTANT STEPS WHEN MOVING THE APPLIANCE

- Unplug the appliance and close the water inlet tap.
- Check, if the door and the detergent dispenser are closed properly.
- Remove the water inlet pipe and the outlet hose from the house installations.
- Let the water drain completely from the appliance (see "Maintenance Cleaning the drain pump filter")
- Important: Re-install the 4 transport bolts in the back of the appliance.
- This appliance is heavy. Transport with care. Never hold any protruding part of the machine when lifting. The machine door can not be used as a handle.

### 5 TECHNICAL SPECIFICATION



Supplier's name or trade mark()(	me or trade mark(a)'(c)	trade	or	name	er's	Supplier
----------------------------------	-------------------------	-------	----	------	------	----------

Supplier's address(a)'(c):

Model identifier(a): MF200W70WB Series

#### General product parameters:

Parameter	Va	lue	Parameter	Va	ilue	
				Height	85	
Rated capacity (b) (kg)	7	.0	Dimensions in cm (a), (c)	Width	60	
				Depth	50	
Energy efficiency index (b) (EEI <sub>W</sub> )	60	0.0	Energy efficiency class (b)	В	( <sup>d</sup> )	
Washing efficiency index (b)	1.0	031	Rinsing effectiveness (g/kg) (b)	5	.0	
Energy consumption in kWh per cycle, based on the eco 40-60 programme. Actual energy consumption will depend on how the appli- ance is used.	Water consumption in litre per cycle, based on the eco 40-60 programme. Actual water consumption will depend on how the appliance is used and on the hardness of the water.		4	15		
Maximum temperature inside the treated textile (b) (°C)	Rated capacity	40	W. 1. 1	53.9		
	Half	32	Weighted remaining moisture content (b) (%)			
	Quarter	28				
	Rated capacity	1350				
Spin speed (b) (rpm)	Half	1350	Spin-drying efficiency class (b)	В	( <sup>d</sup> )	
	Quarter	1350				
	Rated capacity	3:28				
Programme duration (b) (h:min)	Half	2:42	Туре	free-s	free-standing	
	Quarter	2:42				
Airborne acoustical noise emissions in the spinning phase (a) (dB(A) re 1 pW)	76		Airborne acoustical noise emission class ( <sup>b</sup> ) (spinning phase)	B ( <sup>d</sup> )		
Off-mode (W) (if applicable)	0.:	50	Standby mode (W) (if applicable)	N	7/A	
Delay start (W) (if applicable)	4.0	00	Networked standby (W) (if applicable)	2.0	00	

#### Minimum duration of the guarantee offered by the supplier (a)'(c):

This product has been designed to release silver ions	NO
during the washing cycle	NO

#### Additional information:

- (a) this item shall not be considered relevant for the purposes of Article 2(6) of Regulation (EU) 2017/1369.
- (b) for the eco 40-60 programme.
- (°) changes to this item shall not be considered relevant for the purposes of paragraph 4 of Article 4 of Regulation (EU) 2017/1369.
- (d) if the product database automatically generates the definitive content of this cell, the supplier shall not enter these data.

Supplier's name or trade i	mark(a)'(c):
----------------------------	--------------

Supplier's address(a)'(c):

Model identifier(a): MF200W80WB Series

#### General product parameters:

Parameter	Va	lue	Parameter		lue
				Height	85
Rated capacity (b) (kg)	8.0		Dimensions in cm (a), (c)	Width	60
				Depth	48
Energy efficiency index (b) (EEI <sub>W</sub> )	51	.9	Energy efficiency class (b)	A (d)	
Washing efficiency index (b)	1.0	031	Rinsing effectiveness (g/kg) ( <sup>b</sup> )	5	.0
Energy consumption in kWh per cycle, based on the eco 40-60 programme. Actual energy consumption will depend on how the appli- ance is used.		Water consumption in litre per cycle, based on the eco 40-60 programme. Actual water consumption will depend on how the appliance is used and on the hardness of the water.		48	
Maximum temperature inside the treated textile $\binom{b}{i}$ (°C)	Rated capacity	37	Weighted remaining moisture	53.9	
	Half	31	content (b) (%)		
	Quarter	22			
	Rated capacity	1350			
Spin speed (b) (rpm)	Half	1350	Spin-drying efficiency class (b)	В	( <sup>d</sup> )
	Quarter	1350			
	Rated capacity	3:38			
Programme duration (b) (h:min)	Half	2:48	Туре	free-st	anding
	Quarter	2:48			
Airborne acoustical noise emissions in the spinning phase (a) (dB(A) re 1 pW)	7	6	Airborne acoustical noise emission class ( <sup>b</sup> ) (spinning phase)	В	( <sup>d</sup> )
Off-mode (W) (if applicable)	0.:	50	Standby mode (W) (if applicable)	N	/A
Delay start (W) (if applicable)	4.0	00	Networked standby (W) (if applicable)	2.0	00

#### Minimum duration of the guarantee offered by the supplier (a)(c):

	11.11
This product has been designed to release silver ions	NO
during the washing cycle	NO

### Additional information:

- (a) this item shall not be considered relevant for the purposes of Article 2(6) of Regulation (EU) 2017/1369.
- (b) for the eco 40-60 programme.
- (°) changes to this item shall not be considered relevant for the purposes of paragraph 4 of Article 4 of Regulation (EU) 2017/1369.
- (d) if the product database automatically generates the definitive content of this cell, the supplier shall not enter these data.

Supplier's	name	or trade	mark(a	)'(°)	:
------------	------	----------	--------	-------	---

Supplier's address(a)'(c):

Model identifier(a): MF200W90WB Series

### General product parameters:

Parameter	Va	lue	Parameter	Value	
				Height	85
Rated capacity (b) (kg)	9	.0	Dimensions in cm (a), (c)	Width	60
				Depth	54
Energy efficiency index (b) (EEI <sub>W</sub> )	51	.9	Energy efficiency class (b)	A	( <sup>d</sup> )
Washing efficiency index (b)	1.0	031	Rinsing effectiveness (g/kg) (b)	5	.0
Energy consumption in kWh per cycle, based on the eco 40-60 programme. Actual energy consumption will depend on how the appli- ance is used.	cycle, 0.494 progra sumpi applia		Water consumption in litre per cycle, based on the eco 40-60 programme. Actual water consumption will depend on how the appliance is used and on the hardness of the water.	50	
Maximum temperature inside the treated textile $\binom{b}{1}$ $\binom{o}{1}$	Rated capacity	39	Weighted remaining moisture	53.9	
	Half	28	content (b) (%)		
	Quarter	22			
	Rated capacity 1300				
Spin speed (b) (rpm)	Half	1300	Spin-drying efficiency class (b)	В	( <sup>d</sup> )
	Quarter	1300			
	Rated capacity	3:48			
Programme duration (b) (h:min)	Half	2:54	Type	free-s	tanding
	Quarter	2:54			
Airborne acoustical noise emissions in the spinning phase (a) (dB(A) re 1 pW)	7	6	Airborne acoustical noise emission class ( <sup>b</sup> ) (spinning phase)	B ( <sup>d</sup> )	
Off-mode (W) (if applicable)	0.:	50	Standby mode (W) (if applicable)	N	7/A
Delay start (W) (if applicable)	4.0	00	Networked standby (W) (if applicable)	2.00	

#### Minimum duration of the guarantee offered by the supplier (a)'(c):

This product has been designed to release silver ions	NO
during the washing cycle	NO

#### Additional information:

- (a) this item shall not be considered relevant for the purposes of Article 2(6) of Regulation (EU) 2017/1369.
- (b) for the eco 40-60 programme.
- (°) changes to this item shall not be considered relevant for the purposes of paragraph 4 of Article 4 of Regulation (EU) 2017/1369.
- (d) if the product database automatically generates the definitive content of this cell, the supplier shall not enter these data.

Supplier's	name	or trade	mark(a	)'(°)	:
------------	------	----------	--------	-------	---

Supplier's address(a)'(c):

Model identifier(a): MF200W100WB Series

#### General product parameters:

Parameter	Va	lue	Parameter	Value		
	10.0			Height	85	
Rated capacity (b) (kg)			Dimensions in cm ( <sup>a</sup> ), ( <sup>c</sup> )	Width	60	
				Depth	57	
Energy efficiency index (b) (EEI <sub>W</sub> )	51.9 Energy efficiency class (b)		Energy efficiency class (b)	A (d)		
Washing efficiency index (b)	1.0	031	Rinsing effectiveness (g/kg) ( <sup>b</sup> )	5.0		
Energy consumption in kWh per cycle, based on the eco 40-60 programme. Actual energy consumption will depend on how the appli- ance is used.		513	Water consumption in litre per cycle, based on the eco 40-60 programme. Actual water consumption will depend on how the appliance is used and on the hardness of the water.	52		
Maximum temperature inside the treated textile (b) (°C)	Rated capacity	35	Weighted remaining moisture	53.9		
	Half	30	content (b) (%)			
	Quarter	22				
Spin speed ( <sup>b</sup> ) (rpm)	Rated capacity	1350		B ( <sup>d</sup> )		
	Half	1350	Spin-drying efficiency class (b)		( <sup>d</sup> )	
	Quarter	1350				
	Rated capacity	3:59				
Programme duration (b) (h:min)	Half	3:00	Туре	free-standing		
	Quarter	3:00				
Airborne acoustical noise emissions in the spinning phase (a) (dB(A) re 1 pW)	80		Airborne acoustical noise emission class ( <sup>b</sup> ) (spinning phase)	С	( <sup>d</sup> )	
Off-mode (W) (if applicable)	0.:	50	Standby mode (W) (if applicable)	N	/A	
Delay start (W) (if applicable)	4.00 Networked standby (W) (if applicable)			2.00		

#### Minimum duration of the guarantee offered by the supplier (a)(c):

This product has been designed to release silver ions	NO
during the washing cycle	NO

### Additional information:

- (a) this item shall not be considered relevant for the purposes of Article 2(6) of Regulation (EU) 2017/1369.
- (b) for the eco 40-60 programme.
- (°) changes to this item shall not be considered relevant for the purposes of paragraph 4 of Article 4 of Regulation (EU) 2017/1369.
- (d) if the product database automatically generates the definitive content of this cell, the supplier shall not enter these data.

Supplier's	name	or trade	mark(a	)'(°)	:
------------	------	----------	--------	-------	---

Supplier's address(a)'(c):

Model identifier(a): MF200W120WB Series

#### General product parameters:

Parameter	Va	lue	Parameter	Value		
	12.0			Height	85	
Rated capacity (b) (kg)			Dimensions in cm (a), (c)	Width	60	
				Depth	60	
Energy efficiency index (b) (EEI <sub>W</sub> )	52.0		Energy efficiency class (b)	A (d)		
Washing efficiency index (b)	1.0	031	Rinsing effectiveness (g/kg) ( <sup>b</sup> )	5.0		
Energy consumption in kWh per cycle, based on the eco 40-60 programme. Actual energy consumption will depend on how the appli- ance is used.	**	544	Water consumption in litre per cycle, based on the eco 40-60 programme. Actual water consumption will depend on how the appliance is used and on the hardness of the water.	57		
Maximum temperature inside the treated textile (b) (°C)	Rated capacity	42	Weight description and interest	53.9		
	Half	30	Weighted remaining moisture content (b) (%)			
	Quarter	23				
Spin speed ( <sup>b</sup> ) (rpm)	Rated capacity	1350		B ( <sup>d</sup> )		
	Half	1350	Spin-drying efficiency class (b)		( <sup>d</sup> )	
	Quarter	1350				
	Rated capacity	4:00				
Programme duration (b) (h:min)	Half	3:00	Туре	free-standing		
	Quarter	3:00				
Airborne acoustical noise emissions in the spinning phase (a) (dB(A) re 1 pW)	80		Airborne acoustical noise emission class ( <sup>b</sup> ) (spinning phase)	С	( <sup>d</sup> )	
Off-mode (W) (if applicable)	0.:	50	Standby mode (W) (if applicable)	N/A		
Delay start (W) (if applicable)	4.00		Networked standby (W) (if applicable)	2.00		

#### Minimum duration of the guarantee offered by the supplier (a)'(c):

This product has been designed to release silver ions	NO
during the washing cycle	NO

### Additional information:

- (a) this item shall not be considered relevant for the purposes of Article 2(6) of Regulation (EU) 2017/1369.
- (b) for the eco 40-60 programme.
- (°) changes to this item shall not be considered relevant for the purposes of paragraph 4 of Article 4 of Regulation (EU) 2017/1369.
- (d) if the product database automatically generates the definitive content of this cell, the supplier shall not enter these data.

- The actual energy consumption will depend on how the appliance is used.
- 2) The actual water consumption will depend on how the appliance is used and on the hardness of the water.
- 3) Delivery of the spare parts within 15 working days after having received the order.

Product Data Sheet concerning (EU) 2019/2014, (EU) 2019/2023, (EU) 2021/340, (EU) 2021/341.

The product data sheet for your appliance can be found online. Go to https://eprel.ec.europa.eu and enter the model identifier for your appliance to download the data sheet. The model identifier for your appliance can be found in the technical specifications section.

### 7 SMART FUNCTION



### Use Your Appliance with the MSmartHome App

Before you start, make sure that:

- 1. Your smartphone is connected to home WiFi network, and you know the network password.
- 2. Make sure you are near the home appliance.
- 3. The 2.4GHz band wireless signal is enabled on your wireless router.

### Follow the below steps to enter the remote control state

### Download the MSmartHome app

On an app market (Google Play Store, Apple App Store), search for "MSmartHome" and find the MSmartHome app. Download and install it on your phone. You can also download the app by scanning the QR code below.



### Register and log in

Open the MSmartHome app, and create a new account to start (you can also register through a third-party account). If you already had an existing account, use the account to log in.



### **Connect your devices to MSmartHome**

- 1: Please make sure your mobile phone is connected to WiFi. If not, go to Settings and turn on the wireless connection, select and connect to a WiFi. Also please turn on the Bluetooth on your phone. If not, go to Settings and turn it on.
- 2:Please power on your devices.
- 3:Open MSmartHome app on your phone.

# **7 SMART FUNCTION**



4:If a message of "Smart devices discovered nearby" appears, click to add.



5:If no message appears, select "+" on the page and select your device in the list of nearby devices available. If your device is not listed, please add your device manually by the device category and device model.



6:Connect your device to WiFi according to the instructions on app, if the connection fails, please follow the instructions provided by the app to continue with the operation.



7. Start the remote control

### 7 SMART FUNCTION



### WiFi Status Light

Slowly flashing	Waiting for connection
Quickly flashing	Connecting
 Quickly flashing solid	Connected to your wireless router

# ∕!\ Notes

- Make sure your devices are powered on.
- Keep your mobile phone close enough to your device when you are connecting network to your device.
- Connect your mobile phone to the wireless network at home, and make sure you know the password of the WiFi.
- Check if your router supports 2.4 GHz WiFi band and turn it on. If you are not sure whether the router supports 2.4 GHz band, please contact the router manufacturer.
- The device cannot connect to the WiFi that requires authentication, and it usually appears in public area such as hotels, restaurants, etc. Please connect to a WiFi that does not require authentication.
- It is recommended to use a WiFi name that only contains letters and numbers. If your WiFi name contains special characters, please modify it in the router.
- Turn off the WLAN+ (Android) or WLAN Assistant (iOS) function of your mobile phone when connecting network to your devices.
- In the case that your device connected to WiFi before but it needs to reconnect, please click "+" on app Home page, and add your device again by the device category and model according to the instructions on app.

Procedures to turn off the WiFi function.

1. Press [ Temp. ] 3 seconds to turn off the WiFi function.

Procedures to turn on the WiFi function

1. Press [ 3 ] 3 seconds to turn on the WiFi function.

Procedures to reset the WiFi configuration.

- 1. Press [ † ] 3 seconds to turn on the WiFi function and re-enter the network configuration process.
- 2. "AP" will be displayed on the knob display.
- 3. Reconnect to the network based on the content of previous page.

#### **NOTES**

# Warranty

We provide a guarantee for this machine in accordance with the following conditions: You have a manufacturer's warranty of \_\_\_\_ years from the date of purchase (proof of purchase must be provided). Our General Terms and Conditions apply.

Your device / serial number	
Purchase date:	
Place of purchase:	

Do you have any questions?
We are happy to support you!

