cecotec

THERMOSENSE 210 STEEL

Hervidor de agua / Electric kettle



Manual de instrucciones
Instruction manual
Manuel d'instructions
Bedienungsanleitung
Manuale di istruzioni
Manual de instruções
Handleiding
Instrukcja obsługi
Návod k použití

1. PARTS AND COMPONENTS

1. Cover
2. Spout
3. Stainless-steel body
4. Base
5. Cover opening button
6. Handle
7. Water level indicator
8. Power switch

NOTE:
The graphics in this manual are schematic representations and may not exactly match the device.

2. BEFORE USE

- This appliance is packaged in a way as to protect it during transport. Take the appliance out of its box and remove all packaging materials. You can keep the original box and other packaging elements in a safe place. This will help you prevent damage to the appliance when transporting it in the future. In case the original packaging is disposed of, make sure all packaging materials are recycled accordingly.
- Make sure all parts and components are included and in good conditions. If there is any piece missing or in bad conditions, contact the official Cecotec Technical Support Service immediately.

Box content
- Kettle and base
- Instruction manual

3. OPERATION

Basic instructions for using the kettle
- The refilled water level must be between the "MIN" and "MAX" marks.
- Switch the kettle off before removing it from the base.
- Close the cover and make sure it is securely closed.
- The base and exterior of the kettle must not get wet.
- The body of the appliance must fit the base.

- Do not open the cover when pouring.
- Be careful when opening the cover to avoid splashing condensed water on the it.

Using the kettle for the first time

NOTE: before using the kettle for the first time, fill it with water and boil it twice. Do not add any other product.
NOTE: press the cover opening button to open the cover.

1. Fill the kettle with water, but do not exceed the MAX mark. Please consider the water level indicator.
2. Place the kettle on the base.
3. Electrical connections
- Check if the voltage you are going to use is the same as that of the kettle. Further information can be found on the label on the base of the kettle.
- Only connect the appliance to a correctly installed 220-240 V~ 50/60 Hz power socket.
4. Switch on the kettle by pressing the power switch. The indicator light will light up indicating that the water is heating up.
5. After the water has boiled, the appliance will automatically switch off.

NOTE: disconnect it from the mains.
NOTE: do not touch or pick up the appliance after use by any part other than the handle, since the kettle reaches high temperatures and can be dangerous.
NOTE: do not use the appliance without the limescale filter, since this can be dangerous due to boiling water coming out of the pouring spout.

4. CLEANING AND MAINTENANCE

- Before cleaning the kettle, unplug it and allow it to cool down.
- Clean the outside of the appliance with a slightly damp sponge or cloth.
- Never immerse the appliance in water or other liquids.
- Do not use abrasive cleaners, metal brushes or any other object that may scratch the surface.
- When you notice limescale deposits on the base of the kettle, descale the kettle using a recommended descaler according to the manufacturer's instructions.

5. TROUBLESHOOTING

Problem	Solutions
The kettle does not switch on	Check that it is correctly connected to the mains. Make sure that the plug works. Make sure the switch was pressed down.
The kettle does not boil water	Make sure that the water is between the minimum and maximum level. Check that it is correctly connected to the mains. Check that the water is not already hot.
The kettle does not switch off automatically	Check that the cover is correctly fitted.

6. TECHNICAL SPECIFICATIONS

Product reference: 01425
Product: Thermosense 210 Steel electric kettle
Power: 1850-2200 W
Voltage: 220-240 V
Frequency: 50/60 Hz
Maximum capacity: 1.7 l

Technical specifications may change without prior notification to improve product quality.
Made in China | Designed in Spain

7. DISPOSAL OF OLD ELECTRICAL AND ELECTRONIC APPLIANCES



This symbol indicates that, according to the applicable regulations, the product and/or batteries must be disposed of separately from household waste. When this product reaches the end of its shelf life, you should dispose of the cells/batteries/accumulators and take them to a collection point designated by the local authorities.
Consumers must contact their local authorities or retailer for information concerning the correct disposal of old appliances and/or their batteries.
Compliance with the above guidelines will help protecting the environment.

8. TECHNICAL SUPPORT AND WARRANTY

Cecotec shall be liable to the end user or consumer for any lack of conformity that exists at the time of delivery of the product under the terms, conditions, and deadlines established by the applicable regulations.
It is recommended that repairs be carried out by qualified personnel.
If at any moment you detect any problem with your product or have any doubt, do not hesitate to contact the official Cecotec Technical Support Service at +34 963 210 728.

9. COPYRIGHT

The intellectual property rights over the texts in this manual belong to CECOTEC INNOVACIONES, S.L. All rights reserved. The contents of this publication may not, in whole or in part, be reproduced, stored in a retrieval system, transmitted, or distributed by any means (electronic, mechanical, photocopying, recording or similar) without the prior authorization of CECOTEC INNOVACIONES, S.L.