


EVOLVE

Quick Start Guide

LET'S GET STARTED!

MODEL NUMBER
468921224
468922224


Char-Broil®



GB	Quick Start Guide	2
CH,FR	Guide de démarrage rapide	4
LU,AT,CH,DE	Schnellstartanleitung	6
CH,IT	Guida Rapida	8
SE	Snabbstartsguide	10
ES	Guía de inicio rápido	12
DK	Vejledning til hurtig start	14
NO	Hurtigstartveiledning	16
SK	Sprievodca rýchlym spustením	18
CZ	Rychlý návod	20
HU	Gyors üzembe helyezési útmutató	22
SI	Vodnik za hiter začetek	24



QUICK START



POWER ON / OFF

Press the power button to turn the grill on. Press and hold the power button for three seconds to turn the grill off.



SET TEMPERATURE

Both temperature zones are initially synchronized. Move the control knob clockwise to set a higher temperature. Press the knob and wait until the light ring stops pulsating, indicating target temperature is reached.. The display alternates between the current and the desired temperature, "Set" and "Act" flash. Turning counterclockwise decreases the temperature.

TEMPERATURE UNITS

To convert temperature units, press the timer and AutoClean buttons together while the controller is ON.



SEPARATE ZONES

To set the zones individually, press the grill symbol above the temperature display on the selected side. This allows the temperature to be set for the selected zone.



SYNCHRONIZE ZONES

To synchronize the zones again, rotate the control knob to desired temperature and press the knob to confirm.

QUICK START



TURNING ZONES ON AND OFF A long press on a grill symbol switches the respective zone off completely. To switch to on again, press the symbol until it lights up again.



TIMER & CORE TEMPERATURE Pressing the stopwatch symbol activates the timer. The display flashes 00:00. Use the rotary knob to set the time in 30-second increments and confirm by pressing. The LEDs for the food temperature sensors are also located on the left. They show the temperatures as soon as they are connected to the grill.



AUTOCLEAN With the lid closed, press the AutoClean symbol for two seconds until the light ring lights up. The EVOLVE switches off automatically as soon as the program is completed. To interrupt the process, press the AutoClean symbol for two seconds and the EVOLVE returns to the last setting,



ERRORS All error codes are explained in the interactive assembly instructions, if you have any questions, our customer service will be happy to help: charbroil.co.uk/contact-us

Char-Broil®

GB	NOTE: This information is a guide only. Items included in your BBQ specification may differ depending on region or specific dealer specification.	All specifications are subject to change without notice.
CH, FR	NOTE: Ces renseignements sont donnés à titre indicatif. Il est possible que les articles inclus dans les spécifications de votre barbecue diffèrent selon la région ou les caractéristiques stipulées par le concessionnaire.	Toutes les caractéristiques sont susceptibles d'être modifiées
LU, AT, CH, DE	ANMERKUNG: Diese Anleitung dient nur zu Informationszwecken. Einzelteile der Grillspezifikation sind unter Umständen verschieden entsprechend der Vertriebsregion oder bestimmten Händleranforderungen.	Änderungen ohne vorherige Bekanntgabe vorbehalten.
CH, IT	AVVERTENZA: Queste informazioni hanno il valore di guida soltanto. Gli articoli compresi nelle caratteristiche tecniche del barbecue potrebbero variare a seconda della regione o del concessionario.	Tutti i dati tecnici possono cambiare senza preavviso.
SE	ANM.: Denna information är endast avsedd som handledning. Specifikationerna för grillen kan variera regionalt eller beroende på de krav som olika återförsäljare har.	Kaikki oikeudet teknisten tietojen muutoksiin pidätetään.
ES	NOTA: Esta información es una guía únicamente. Es posible que las indicaciones incluidas en las especificaciones de su Asador sean diferentes según la región o las especificaciones específicas del representante.	Todas las especificaciones están sujetas a cambios sin previo aviso.
DK	NB.: Denne information er kun vejledende. Specifikationer kan variere efter Ænske fra forhandler, eller i henhold til nationale regler.	Alle specifikationer kan ændres foruden varsel.
NO	NB.: Denne informasjon er kun veiledende. Spesifikasjoner kan variere som stipulert av forhandler, eller i henhold til nasjonale krav.	Spesifikasjoner kan endres uten varsel.
SK	POZNÁMKA: Tieto informácie slúžia len ako pomôcka. Údaje uvedené v technických údajoch vášho grilu sa môžu líšiť podľa regiónu alebo špecifických technických údajov stanovených predajcom.	Všetky špecifikácie sa môžu zmeniť bez upozornenia.
CZ	POZNÁMKA: Tyto informace slouží pouze jako instruktaž. Součásti vašeho BBQ. Specifikace se mohou lišit podle regionu/země nebo specifických údajů prodejce.	Všechny informace mohou být změněny bez předchozího upozornění.
HU	MEGJEGYZÉS: Ez az információ csak tájékoztató jellegű. A BBQ specifikációjában szereplő tételek a régiótól vagy a specifikus kereskedői specifikációtól függően eltérőek lehetnek.	Minden műszaki változtatás jogát fenntartjuk.
SI	OPOMBA: Te informacije so le vodnik. Predmeti, vključeni v vašo specifikacijo BBQ, se lahko razlikujejo glede na regijo ali specifikacijo prodajalca.	Vse specifikacije se lahko spremenijo brez predhodnega obvestila.

